

STERILEX® SPREADERS



RECOMMENDED PUSH SPREADERS

80 lb Capacity: Model# 2050P

RECOMMENDATION OVERVIEW

Sterilex completed in-house testing to evaluate the capabilities of multiple spreaders obtained from Northern Tool and Equipment. Other spreaders may work, but should be checked to ensure they can apply at the required use rate.

The Earthway® Walk-Behind Spreader performed the best during in-house evaluations and is a great way to disperse powdered products in large areas such as warehouses. When used to spread Sterilex Ultra Step and ProvaStride™, this ensures large area protection from foodborne pathogens like *Listeria*, *E. Coli* and *Salmonella*.

The Earthway Walk-Behind Spreader arrives fully assembled.

BENEFITS

Durable

- Patented EV-N-SPRED® 3-hole drop shutoff system and heavy duty gearbox ensure an even spread
- Commercial-quality gearbox with enclosed gears

Accurate Dosing

- Patented SideSpread-Control maintains the correct application rate while eliminating the need for a side deflector
- SideSpread controls the speed pattern to the front and right of the spreader
- Effectively spreads powder at lower hopper capacities

Easy Application

- Fingertip rate control setting located high on the handle for precise adjustments
- Rate calculation matrix to assist in setting for all granular products
- Large spread radius – may reduce time spent spreading powder

Hygienic Design

- 10 inch pneumatic wheels
- Rustproof poly hopper
- Cushioned grip

APPLICATION INSTRUCTIONS

(See product label for full usage instructions)

1. Pre-measure enough Sterilex Ultra Step or ProvaStride to cover the surface area (see application guides for estimation).
2. Slowly add Sterilex Ultra Step or ProvaStride to the spreader, hopper or application device.
3. Set the use rate setting on the Earthway Walk-Behind Spreader to 10–15 to ensure proper application rate.* The Sterilex handheld spreader should be used at setting 2.5.* If this use rate is too high for the calculated weight, adjust down until the smallest amount of Sterilex Ultra Step or ProvaStride is regularly released.
4. Walk forward at a deliberate pace (~3mph). Pull handle (or engage trigger) to begin application.
5. Floor should have a light coating of Sterilex Ultra Step or ProvaStride, and ensure minimum label requirements of coverage.
6. When floor surface has no more undissolved Sterilex Ultra Step or ProvaStride, it's time to reapply.



STERILEX HANDHELD SPREADER

- 5 lb capacity
- Funnel-shaped design tailored for ideal material flow
- Reinforced, contoured lip design for easy scooping
- Calibrated specifically for Sterilex Ultra Step or ProvaStride use
- Ergonomic trigger handle

*These settings are meant as a guide only, results may vary. The product must be used at the labeled minimum use rate to achieve claim efficacy. See product label or application guide to calculate correct usage rates for your facility.